








BMW F900GS '24-

M O U N T I N G I N S T R U C T I O N S

REF 21980

TOURING SCREEN




| ID. | PIEZA/PART | DESCRIPCIÓN | DESCRIPTION | QTY. | REF.: |
|-----|---|--|---|------|-----------------|
| 1 |  | Cúpula Touring | Touring screen | 1 | 21980W/H/FM3 |
| 2 |  | Tornillo especial M5x9 Long Hexagonal 14 (Rosca int M5x12) | M5x9 special screw, Hexagonal length 14 (M5x12) | 4 | TORNI-EC----597 |
| 3 |  | Arandela metálica M5 DIN 9021 Ø5,3x Ø15 x1,2 (Negra) | M5 DIN 9021 Ø5,3x Ø15 x1,2 Washer | 4 | ARAND-PD5---152 |
| 4 |  | Silentblock Ø12xØ6x9 | Ø12xØ6x9 Silentblock | 4 | AROPASACABLES-1 |
| 5 |  | casquillo con valona Ø12xØ6,8x7,3 | Ø12xØ6,8x7,3 Bush with flange | 4 | CASQUI-1A---750 |
| 6 |  | Tornillo allen M5x16 Ø11 ISO 7380 | M5x16 Ø11 ISO 7380 Allen screw | 4 | TORNI-I7380-493 |
| 7 |  | Tapón tornillo M5 ISO 7380 | M5 ISO 7380 Screw cap | 4 | TAPON-----85 |

BMW F900GS '24-

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG


1

**DISASSEMBLY
DESMONTAJE**




2

**ASSEMBLY
MONTAJE**



3

**ASSEMBLY
MONTAJE**



5 Par de apriete - 3,5 Nm
Tightening torque - 3,5 Nm

2.0 MULTI-ADJUSTABLE VISOR (FIX)


M O U N T I N G I N S T R U C T I O N S

REF 20763

UNIVERSAL (FIXED VERSION)



1 Person



Ø7



15 min



PHILLIPS
SCREWDRIVER



EASY

ALLEN
Nº 4




| ID | PIEZA/PART | DESCRIPCIÓN | DESCRIPTION | QTY | REF |
|----|---|-------------------------------------|---------------------------------|-----|----------------------|
| 1 |  | Visera de policarbonato antirayadas | Antiscratch polycarbonate Visor | 1 | 20765H/WM3 |
| 2 |  | Plantilla | Template | 1 | PLANTILLA-VISOR |
| 3 |  | Mecanismo Izquierdo | Left Mechanism | 1 | See exploding page 2 |
| 4 |  | Mecanismo Derecho | Right Mechanism | 1 | See exploding page 2 |

2.0 MULTI-ADJUSTABLE VISOR (FIX)

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

1

EXPLOTING



i LINEA DE PARTICIÓN DEL MOLDE DE INYECCIÓN. PARTING LINE OF THE INJECTION MOLD **i**


| ID | PIEZA/PART | DESCRIPCIÓN | DESCRIPTION | QTY | REF |
|----|------------|--------------------------------------|-----------------------------------|-----|-----------------|
| A | | Tapa pieza eje | Axle part cover | 2 | TAPAEJE-VISOR-- |
| B | | Pieza eje | Axle part | 2 | EJE-FIX-VISOR-- |
| L2 | | Tapa 2 Logo | Logo cover 2 | 1 | TAPALAT-VISORL2 |
| R2 | | Tapa 2 Tornillo | Screw cover 2 | 1 | TAPALAT-VISORR2 |
| L1 | | Tapa 1 Logo | Logo cover 1 | 1 | TAPALAT-VISORL1 |
| R1 | | Tapa 1 Tornillo | Screw cover 1 | 1 | TAPALAT-VISORR1 |
| 5 | | Tapa cúpula | screen cover | 2 | TAPAFIX-VISOR-- |
| 6 | | Tornillo allen S.T. 6,3 x14 | S.T. 6,3 x14 Allen screw | 4 | TOZN00M60000258 |
| 7 | | Tornillo Ø3,5x9,5 DIN7981 C (negro) | Ø3,5x9.5 DIN7981 C screw (black) | 2 | TORNI-D7981-907 |
| 8 | | Tapón tornillo M6 | M6 Screw cap | 4 | TAPON-----81 |

2.0 MULTI-ADJUSTABLE VISOR (FIX)

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

2

ASSEMBLY
MONTAJE



PAR APRIETE TORNILLO ID7 1 Nm
TIGHTENING TORQUE FOR ID7 SCREW 1 Nm


2.0 MULTI-ADJUSTABLE VISOR (FIX)

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

3

SCREEN TYPE “ ——— ”


ASSEMBLY
MONTAJE



SCREEN TYPE “ ——— ”

3


ASSEMBLY
MONTAJE



3


SCREEN TYPE “ ——— ”

ASSEMBLY
MONTAJE



4

ASSEMBLY
MONTAJE




2.0 MULTI-ADJUSTABLE VISOR (FIX)

INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

5


ASSEMBLY
MONTAJE



CHAFLANAR LOS 4 AGUJEROS POR AMBOS LADOS.
SE RECOMIENDA REALIZAR CHAFLAN $\varnothing 10\text{mm} - \varnothing 20\text{mm}$
CHAMFER THE FOUR HOLES ON BOTH SIDES.
IT IS RECOMMENDED TO MAKE CHAMFER $\varnothing 10\text{mm} - \varnothing 20\text{mm}$

6

ASSEMBLY
MONTAJE



PAR APRIETE TORNILLO ID6 1,3Nm
TIGHTENING TORQUE FOR ID6 SCREWS 1,3Nm